



# Reference Formula

Sample preparation date: YYYY/MM/ZZ

## Y2Kiss 霧吻我唇膏

T230309

### FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
O1	<b>PERFORMA™ SW-84</b>	<b>Synthetic Wax</b>	<b>10.38%</b>	<b>Thickener</b>
	<b>Synthetic Wax<sup>9</sup></b>			<b>(Oily)</b>
	<b>Paracera™ M<sup>11</sup></b>	<b>Paraffin; Cera</b>	<b>6.74%</b>	<b>Thickener</b>
		<b>Microcristallina</b>		<b>(Oily)</b>
	<b>Paracera™ MW<sup>11</sup></b>	<b>Cera Microcristallina</b>	<b>1.41%</b>	<b>Thickener</b>
			<b>(Oily)</b>	
	<b>ERCAREL ISN V<sup>14</sup></b>	<b>Isononyl Isononanoate</b>	<b>48.54%</b>	<b>Skin feel modifiers</b>
	Polybutene	Polybutene	8.12%	Skin feel modifiers
A	AC 360	Titanium Dioxide	7.39%	Pigment
	Red Iron Oxide	Red Iron Oxide	4.54%	Pigment
	Red #7	Red 7	1.28%	Pigment
	Black Iron Oxide	Black Iron Oxide	0.17%	Pigment
	<b>ES-5700 Formulation Aid<sup>1</sup></b>	<b>CetylDiglyceryl Tris(trimethylsiloxy)silylethyl Dimethicone</b>	<b>2.00%</b>	Dispersant
B	<b>EcoSmooth™ Rice Husk Cosmetic Powder<sup>1</sup></b>	<b>Silica</b>	<b>9.40%</b>	Skin feel modifiers
C	<b>Mango&amp;Papaya<sup>16</sup></b>	<b>Fragrance</b>	<b>0.30%</b>	Fragrance
	Preservative	Preservative	q.s	Preservative

Suppliers: 1. Dow ; 9. Nu Cera; 11. Paramelt; 14. ErcaWilmar 16. Lothar Streeck

### PROCEDURE

1. Heat Phase A to 90-95°C till all the ingredients melt and mix well.
2. Disperse pigments in Phase B, then add to Phase A.
3. Finally add phase C to main tank.
4. Cool down to solidify

The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : [www.essence-plus.com](http://www.essence-plus.com) E-MAIL : [service@essence-plus.com](mailto:service@essence-plus.com)

