



Reference Formula

Sample preparation date: YYYY/MM/ZZ

水潤素顏霜 Hydration Tone Up Cream

Description: **ACULYN™ Siltouch Rheology Modifier**: Emulsifier and thickener for O/W formulations providing a non-tacky, light feel, exhibits versatility across a wide pH range formulation.

•**DOWSIL™ EL-9341 Silicone Elastomer Blend**: Blur skin imperfections, matte appearance, silky and smooth feeling.

DOWSIL™ PMX-1507 Fluid: Provides smooth non-tacky feeling.

FORMULA

| Phase | Ingredient (Trade Name) | Ingredient (INCI Name) | % By Weight | Function |
|-------|---|--|--------------|----------|
| A | Water | Water | To 100 | |
| | Propylene Glycol USP/EP | Propylene Glycol | 4.00% | |
| | Glycerin | Glycerin | 5.00% | |
| | Keltrol CG | Xanthan Gum | 0.05% | |
| | SEPINOV EMT 10 | Hydroxyethyl Acrylate/Sodium Acryloyldimethyl Taurate Copolymer | 0.40% | |
| | NEOLONE PH 100 Preservative | Phenoxyethanol | 1.00% | |
| B | ACULYN™ Siltouch Rheology Modifier | Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer (and) Dimethicone (and) Trideceth-6 (and) PEG/PPG-18/18 Dimethicone | 1.50% | |
| | DOWSIL™ FB-9341 Silicone Elastomer Blend | Dimethicone (and) Dimethicone Crosspolymer | 3.00% | |
| | XIAMETER™ PMX- 200 Fluid, 350 cst | Dimethicone | 4.00% | |

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Sample preparation date: YYYY/MM/ZZ

| | | | |
|---|--|---|--------------|
| | XIAMETER™ PMX-1507 Fluid | Dimethicone(and)Dime thiconol | 1.50% |
| | XIAMETER™ PMX- 200 Fluid, 5 cst | Dimethicone | 4.00% |
| B | Ti-18 AS | CI 77891(and) Aluminum hydroxide (and) Triethoxycaprylsiane | 2.70% |
| | YOUTH CODE | Perfume | 0.1. |

PROCEDURE

1. Mix phase A well.
2. Mix phase B well.
3. Add phase B to phase A with high speed stirring.
4. Homogenize for 2-3 minutes until uniform.

The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

