



Reference Formula

Created Date : 03/19/2025

彈潤妝前乳 Hydra-Bounce Primer

E250319-3

Description: 9586LC Primer is a refreshing, non-sticky and moisturizing makeup base. It uses **ACULYN™ Siltouch Rheology Modifier** as an emulsifier to create a light, watery feel, and add **Dowsil™ FB-9586 LC** to achieve smooth lines and refreshing skin feel. **Xiameter™ PMX- 200 fluid, 2 cst** and **Xiameter™ PMX- 200 fluid, 5 cst** are also used to provide smooth, soft and moisturizing effects. **HYA-ACT™ S** is a small molecule, high-purity hyaluronic acid that provides excellent moisturizing properties.

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
O	Aculyn™ Siltouch Rheology Modifier¹	Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer(and)Dimethicone(and)T rideceth-6(and)PEG/PPG-18/18 Dimethicone	2.40%	Surfactant
	Dowsil™ FB-9586 LC Elastomer¹ Blend¹	Dimethicone(and)Dimethicone Crosspolymer	20.00%	Skin feel modifier
	Xiameter™ PMX- 200 fluid, 2 cst¹	Dimethicone	6.00%	Emollient
	Xiameter™ PMX- 200 fluid, 5 cst¹	Dimethicone	4.30%	Emollient
	W1	D.I Water Xanthan gum HYA-ACT™ S²	D.I Water Xanthan gum Sodium Hyaluronate	49.25% 0.20% 0.05%
W2	Propylene Glycol	Propylene Glycol	5.00%	Moisturizer
	Glycerine USP	Glycerine	5.40%	Moisturizer
	1,3-BG	Butylene Glycol	6.80%	Moisturizer
A	Espinosa		0.30%	Perfume
	GPL	DMDM Hydantoin (and) Iodopropynyl Butylcarbamate	0.30%	Preservative

Supplier: 1.DOW; 2.DSM

PROCEDURE

1. Prepare Phase O and Phase W1 separately, then add W2 to W1.
2. Add phase W1+2 to O under stirring.
3. Add Phase A to the main tank.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Created Date : 03/19/2025

SPECIFICATION

APPEARANCE	: Gel	
VISCOSITY	: approx. 40420 \pm 10%	(RVDV-E, RV6, 12 rpm, 3 min, 25°C)



The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

