



Reference Formula

Created Date : 03/19/2025

9586LC Primer

EP-SC-COW-0117A V1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight
A	Aculyn™ Siltouch Rheology Modifier (Dow Corning)	Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer(and)Dimethicone(and)Trideceth-6(and)PEG/PPG-18/18 Dimethicone	2.40%
	Dowsil™ FB-9586 LC Elastomer (Dow Corning) Blend (Dow Corning)	Dimethicone(and)Dimethicone Crosspolymer	20.00%
	Xiameter™ PMX-0245 Fluid (Dow Corning)	Cyclopentasiloxane	6.00%
	Xiameter™ PMX- 200 fluid, 5 cst (Dow Corning)	Dimethicone	4.00%
B	D.I Water	D.I Water	49.1%
	Propylene Glycol	Propylene Glycol	5.00%
	Glycerine USP	Glycerine	6.00%
	1,3-BG	Butylene Glycol	7.00%
	Xanthan gum	Xanthan gum	0.20%
	GPL	DMDM Hydantoin (and) Iodopropynyl Butylcarbamate	0.30%

PROCEDURE

1. Prepare Phase A and Phase B separately.
2. Add Phase B to A slowly under stirring.

SPECIFICATION

APPEARANCE	: Gel	
VISCOSITY	: approx. 40420 ± 10%	(RVDV-E, RV6, 12 rpm, 3 min, 25°C)

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Created Date : 03/19/2025



The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

