



# Reference Formula

Last Save Date:6/22/21 3:42 PM

## 乾洗手(A830)

EP-HC-G-0001A V1

### FORMULA

Phase	Ingredient (Trade Name)	Ingredient (Chemical Name)	% By Weight	Function
W	D.I Water	D.I Water	29.86%	Thickener (Aqueous) Neutralizer
	<b>ACUSOL™ 830 Rheology Modifier<sup>1</sup></b>	<b>Acrylic Copolymer</b>	<b>7.14%</b>	
	AMP (95%)	2-amino-2-methyl-1-prop anol	q.s	
A	Alcohol	Ethanol	<b>63.00%</b>	Antiseptic/ Preservative

Suppliers: 1. Dow Chemical

### PROCEDURE

1. Prepare Phase W under stirring.
2. Slowly add Phase A into Phase W.

### SPECIFICATION

APPEARANCE	: Clear Gel	
VISCOSITY	: approx.2350 ± 10%	(RVDV-E, Spindle RV-3, 50 rpm, 3 min, 25°C)
pH	: approx.7.68 ± 0.5	(25°C)

*The information given in this publication is based on our current knowledge and experience and may be used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.*

**Recommendations contained, herein this Reference Formula, are advisory only.**

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : [www.essence-plus.com](http://www.essence-plus.com) E-MAIL : [service@essence-plus.com](mailto:service@essence-plus.com)

