



Reference Formula

Sample preparation date: 2/24/22 4:29 PM

衣物去漬液 EP-HC-WM-0005A_V1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (Chemical Name)	% By Weight	Function
W	D.I Water	D.I Water	up to 100	
	BIO-TERGE® PAS-8S ¹³	SODIUM CAPRYLYL SULFONATE	1.00%	Surfactant
	STEPOSOL® CITRI-MET ¹³	Revolutionary fully formulated solution	6.00%	Surfactant
	Preservative	Preservative	q.s.	Preservative

Suppliers: 13. Stepan

PROCEDURE

1. Prepare Phase W under stirring.

SPECIFICATION

APPEARANCE	: Clear Liquid	
pH	: approx. 9.16 ± 0.5	(25°C)

The information given in this publication is based on our current knowledge and experience and may be used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

