

Reference Formula

淨膚細胞精華Plus

EP-SC-G-0071B_V1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
W1	D.I Water	D.I Water	47.43%	
			0.05%	Chelating
	EDTA-2Na	Edetate Disodium		Agent
	LS Diol ⁵	Methyl Propanediol	5.00%	Moisturizer
	Gellan gum	Gellan gum	0.12%	Thickener
	Conditi guill	Conditiguiti	0.1270	(Aqueous)
	2511 Cosmetic Wax ¹	Bis-PEG-18 Methyl Ether	1.00%	Skin feel mo
		Dimethyl Silane		difiers
	CELLOSIZE™ Polymer		40.00%	Thickener
	PCG-10 ¹ (0.5% soln')	Hydroxyethyl cellulose		(Aqueous)
W2	NaCl	Sodium Chloride	0.60%	Neutralizer
0	Dye(red)		0.05%	
	556 Cosmetic Grade Fluid	Phenyl Trimethicone	2.00%	Emollient
	Sustane SAIB MCT ¹⁷	Sucrose Acetate Isobutyrate	1.80% I	Emollient/
		(and) Caprylic/Capric		Density Adjus
		Triglyceride		t
	dl-α-Tocopheryl Acetate ²	Tocopheryl Acetate	0.20%	Antiseptic/
		reception yr Accurc	0.2078	Preservative
		Camelina Sativa Seed Oil,		
	CLEAR Oléoactif®	Thymus Vulgaris	0.20%	Active
		Flower/Leaf/Stem Extract		
	Eclat ¹⁶	Perfume	0.20%	Fragrance
А		Aqua, Glycerin, Saccharomyces		
	Oxy 229 PF ²	Lysate, Disodium Succinate,	1.00%	
		Phenoxyethanol, Ethylhexylglycerin, Valine,		Active
		Threonine, Glutamic Acid, Glycin		
	Pentavitin ²	Saccharide Isomerate, Aqua, Citr	0.20%	
		Acid, Sodium Citrate		Active
	Microcare MTI	Methylisothiazolinone/	0.15%	Antiseptic/
		lodopropynyl Butylcarbamate		Preservative
	Recommendations cont	ained, herein this Reference Formula, are ad	visory only.	

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C. TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Created Date: 8/8/20 1:48 PM Last Save Date:3/22/21 10:58 AM

Suppliers: 1. Dow Chemical ;2.DSM ;5.Leasun ; 16. Lothar Streeck ; 17. Eastman <u>PROCEDURE</u>

- 1. Prepare Phase W1 and heat to 70-75°C under stirring.
- 2. Add Phase W2 to W1 under stirring till cold down to 40°C.
- 3. Homogenizing for one minute.
- 4. Add Phase O to main tank under stirring at 200-400 rpm.
- 5. Add Phase A under stirring.

SPECIFICATION

|--|

The information given in this publication is based on our current knowledge and experience and my be used at your discretion and risk. It does not

relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must

comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C. TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278 Website : www.essence-plus.com E-MAIL : service@essence-plus.com

