



Reference Formula

Created Date: 2019/10/15.
Last Save Date: 6/12/20 5:47 PM

Silky lipstick

EP-CC-L-0030A_V1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
O1	Performalene™700 EP⁹	Ethylene/Propylene Copolymer	2.00%	Thickener
	PERFORMA™ SW-87 Synthetic Wax	Synthetic wax	6.90%	Thickener
	Paracera™ M¹¹	Paraffin; Cera Microcristallina	3.60%	Thickener
	Panalane® H-300E ^B	Hydrogenated Polyisobutene	6.00%	Emollient
O2	ERCAREL G 20¹⁴	Octyldodecanol	10.00%	Emollient
	Tegosoft OS ^C	Ethylhexyl Stearate	9.00%	Emollient
	2-EHP	2-Ethylhexyl Palmitate	10.20%	Emollient
	Tegosoft TIS ^C	Triisostearin	9.00%	Emollient
	DOWSIL™ 556 Cosmetic Grade Fluid¹	Phenyl Trimethicone	4.00%	Emollient
	2502 Cosmetic Fluid¹	Cetyl Dimethicone	3.00%	Emollient
	VM-2270 Aerogel Fine Particles¹	Silica Silylate	0.80%	Thickener
O3	Sweet Almond Oil Cosmetic Grade¹⁰	Prunus amygdalus dulcis oil and Helianthus annuus seed oil	5.00%	Emollient
A	TiO2	Titanium Dioxide	2.00%	Pigment
	Red No.6	Red No.6	6.00%	Pigment
	Red No.7	Red No.7	2.00%	Pigment
	Talc	Talc	5.00%	Skin feel modifiers
	VALVANCE™ Touch 210²	Silica	3.00%	Skin feel modifiers
	ERCAREL AB¹⁴	C12-C15 Alkyl Benzoate	8.00%	Dispersant
	HallBrite®BHB	Butyloctyl Salicylate	4.00%	Dispersant
	ES-5300 Formulation Aid¹	Lauryl PEG-10 Tris(trimethylsiloxy)silylethyl Dimethicone	0.50%	Dispersant

Suppliers: 1. Dow Chemical; 2. DSM; 9.Nu Cera; 10. Northstar Lipids;

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Created Date: 2019/10/15.
Last Save Date: 6/12/20 5:47 PM

11. Parameit; 14. ErcaWilmar; B. Lipo Chemicals; C. Evonik

PROCEDURE

1. Phase O2 is stirred beforehand to dissolve VM-2270.
 2. Add phase O1 to phase O2 to heat to dissolve.
 3. Add phase O3 to phase O1+2.
 4. Phase A is ground and dispersed.
 5. Add phase A to the O1+2+3 phase, uniformly disperse and fill the mold.
-

The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

